



Husqvarna Viking Topaz 50

Thank you for sewing with us! If you would like an introduction to this sewing machine, please contact makerplace@midlandlibrary.com, or 705-526-4216 ext. 3305. We do not guarantee results. Please follow all the noted guidelines for sewing in the MPL MakerPlace.

You will be asked to leave your photo ID with staff at the desk in exchange for the machine attachments and software USB, and must return these items to a staff member. The cost for using the embroidery machine is \$5 / 15 minutes.

In addition:

Use *only* the attached stylus on the touchscreen (no fingers, pens, scissors)

No straight pins in the embroidery hoop design area or embroidery arm

Use the provided 40-wt rayon thread, not your own, serger thread, or thread from the wall unless approved

Use “R” foot & red needle for embroidery

After rethreading, the machine will automatically fix the new thread in the fabric—immediately after pressing “Start” there will be a small click—the thread has been snipped and can be pulled away

When sewing, hit the foot pedal for Autostop

Turn the machine off while adding the embroidery arm, changing needle, or cleaning

VP3 embroidery design files can be brought in or saved to the machine on a 1 or 2 GB USB stick.

IF YOU DO NOT FOLLOW THESE GUIDELINES OR ANY STAFF INSTRUCTION, YOU WILL BE HELD LIABLE FOR DAMAGE TO THE MACHINE.

Permissible Fabrics

OK:

Natural fibers/cotton-linen-wool
Fine fabrics/silk-satin-taffeta/velvet
Knits
Synthetic fabrics/blends-rayon-polyester
Upholstery
Leather/suede
Extra thick fabrics or multiple layers

NO:

Fur
Reptile skin
Canvas/Twill
Plastic/Rubber

THIS IS THE PLACE.

